

Directions for the use of TEXSPAR and TEXSPAR PLUS

1. For cementitious and latex fortified grout use with GROUT STRIPPER. For epoxy grout or heavy grease and dirt deposits use with LEGSOLVE-IT.
2. Sweep or vacuum the floor of all loose debris. Work in 10' X 10' sections.
3. Mix the appropriate LEGGE liquid cleaner according to the label and flood the floor with mop. Let solution stand for approximately 10 minutes. Water may be used instead of LEGGE liquid cleaners. However, the effectiveness will be diminished.
4. Place a cup full of TEXSPAR® or TEXSPAR® Plus every 2-3 feet. Keep solution wet at all times during this procedure.
5. Use a black nylon stripping pad or equal on smooth surfaces or a NYLO GRIT or SCRUB GRIT II brush (aggressive scrubbing brushes) on textured surfaces.
6. Scrub using a rotary scrubber. Hop the machine on top of the TEXSPAR® and create a slurry. Spread out and scrub with solution slowly in an overlapping pattern. Cross scrub at 90o to ensure proper contact. The solution may be scrubbed manually, but a machine is recommended.
7. Pick up solution with a wet vacuum and rinse several times with water until floor is thoroughly clear of residue.
8. For normal cleaning use NEUTRAL CLEANER, LEGGCLEAN® or CITRONEX®. For increased slip resistance use FLOORSHINE R20®. Follow instructions on the label.



WALTER G. LEGGE CO., INC

444 Central Avenue

Peekskill, NY 10566

1-800-345-3443 FAX 1-800-332-2636

www.leggesystems.com

Email: info@leggesystems.com